

Romeo 60 Layouts

Parameter	Layout 1	Layout 2	Layout 3	Layout 4
Type	Wide Single Sided	Narrow Single Sided	Wide Jumbo	Narrow Jumbo
Paper size	11.5" x 11" - Tractor	8.5" x 11" - Tractor	11.5" x 11" - Tractor	8.5" x 11" - Tractor
Paper size unit	Inches	Inches	Inches	Inches
Paper length	11"	11"	11"	11"
Paper width	11.5"	8.5"	11.5"	8.5"
Lines per page	25	25	22	22
Top margin	1 Line	1 Line	1 Line	1 Line
First line offset	.197"	.197"	.197"	.197"
Left offset	.472"	.472"	.472"	.472"
Right offset	.118"	.118"	.118"	.118"
Bottom offset	0"	0"	0"	0"
Characters per line	40	30	30	21
Binding margin	2 Characters	2 Characters	2 Characters	2 Characters
Page number	Top Right	Top Right	Top Right	Top Right
Duplexing	Single Sided	Single Sided	Single Sided	Single Sided
Braille language	6-Dot	6-Dot	Jumbo braille 3.2 mm	Jumbo braille 3.2 mm
Liblouis table	UEB Grade-2 Version-1	UEB Grade-2 Version-1	UEB Grade-2 Version-1	UEB Grade-2 Version-1
Braille line spacing	Single	Single	Single	Single
Braille cell size	.098"	.098"	.126"	.126"
Graphic cell size	.079"	.079"	.079"	.079"
Folding line	None	None	None	None
Impact energy	Normal	Normal	Normal	Normal
Multiple impact	1 Stroke	1 Stroke	1 Stroke	1 Stroke
Max paper in bin	0	0	0	0
Max pages in volume	All Pages	All Pages	All Pages	All Pages
Volume page number	Off	Off	Off	Off
Reformat	Off	Off	Off	Off
Binding offset	12.0	12.0	16.8	16.8